

# **INSTALLATION GUIDELINES FOR AMCORK UNDERLAYMENT**

You must adhere the Underlayment to the subfloor using DriTac 6200 adhesive applied as a two-part contact glue ( apply the adhesive to the subfloor and to the back of the underlayment ). You can use a spackling knife, flat blade trowel, or a foam painter's roller making sure that the adhesive is flashed (100% transparent) before adhering the underlayment. This will provide the strongest bond.